




FP42UL FP42MUL

FP60UL FP60MUL

## FLAT PANEL CART WITH OR WITHOUT A PULL OUT SHELF



**WARNING:** FP42 carts are intended to hold monitors up to 75 lbs and FP60 carts are intended to hold monitors up to 100 lbs. The use of a TV monitor weighing more than that may result in instability causing possible injury. The top, middle and bottom shelves are intended to hold equipment up to 50 lbs. on each shelf. The pull out shelf on FP42MUL and FP60MUL is intended to support equipment up to 15 lbs.

### PARTS LIST

Cart Models: FP42UL, FP42MUL, FP60UL & FP60MUL

| Qty | Part#    | Description                   | Ref | Qty |
|-----|----------|-------------------------------|-----|-----|
| 1   | 022-3065 | Right Rear Leg Assembly       | AA  | 22  |
| 1   | 022-3066 | Left Rear Leg Assembly        | BB  | 24  |
| 2   | 022-3067 | Front Leg Assemblies          | CC  | 2   |
| 1   | 010-5778 | Top Shelf - FP42 Models       | DD  | 2   |
|     | 010-5794 | Top Shelf - FP60 Models       | EE  | 2   |
| 1   | 010-5135 | Middle Shelf - FP42 Models    | FF  | 4   |
|     | 010-5795 | Middle Shelf - FP60 Models    | GG  | 4   |
| 1   | 010-1892 | Bottom Shelf - FP42 Models    | HH  | 8   |
|     | 010-5796 | Bottom Shelf - FP60 Models    | II  | 4   |
| 1   | 022-2827 | Handle Assembly               | JJ  | 2   |
| 1   | 022-3068 | Monitor Bracket - FP42 Models |     | 1   |
|     | 022-3091 | Monitor Bracket - FP60 Models |     | 1   |
| 2   | 010-4953 | Hook Bars                     |     | 1   |
| 2   | 010-4956 | Stop Brackets                 |     |     |
| 2   | 015-0017 | 5" Stem Casters w/o Lock      |     |     |
| 2   | 015-0018 | 5" Stem Casters with Lock     |     |     |

Pull Out Shelf Models : FP42MUL & FP60MUL

| Qty | Part#    | Description                  |
|-----|----------|------------------------------|
| 2   | 010-5783 | Shelf Brackets - FP42 Models |
|     | 010-5784 | Shelf Brackets - FP60 Models |
| 1   | 010-5782 | Pull Out Shelf               |
| 1   | 030-1468 | Left Outer Slide             |
| 1   | 030-1470 | Right Outer Slide            |
| 2   | 030-1471 | Inner Slides                 |

Electrical Unit Models : FP42UL-E5BK, FP42MUL-EBK,  
FP60UL-E5BK & FP60MUL-E5BK

| Qty | Part#   | Description              |
|-----|---------|--------------------------|
| 1   | E6 UNIT | 6-Outlet Electrical Unit |

### HARDWARE LIST

| Part#        | Description                          |
|--------------|--------------------------------------|
| 030-0300-10T | 5/8" Square Head Bolts               |
| 030-0002     | 5/16-18 Hex Serrated Nuts            |
| 030-1349     | 5/16-18 x 3/4" Hex Hd Screws         |
| SC1048B      | 1/4-20 x 45mm Bolts                  |
| 030-0207     | 1/4-20 Serrated Flange Nuts          |
| 030-0401     | 5/8-18 x 1 1/2" Hex Head Screws      |
| 030-0411     | 5/16-18 Serrated Nuts                |
| 030-0304     | 1/4-20 X 5/8" Combo Truss Hd Screws  |
| 030-0865     | #6 x 1/2" Button Pin-In Hd Screws    |
| 030-0354     | 10-32 x 1 1/2" Button Sockets Screws |
| 010-1106     | Hex Wrench                           |
| 030-1352     | 1/8" Security Pin-In Driver Bit      |



044-2124 Courtesy Hardware Pack

#### This Pack Consists of:


- (4) Metric M4 x 12 Screws
- (4) Metric M4 x 30 Screws
- (4) Metric M5 x 12 Screws
- (4) Metric M5 x 30 Screws
- (4) Metric M6 x 12 Screws
- (4) Metric M6 x 35 Screws
- (8) Small Washers
- (20) Large Washers
- (4) 5/8" Large Spacers

# STEP 1


Position the top shelf onto the rear legs making sure the leg brackets are to inside of the shelf. **LOOSELY** secure the shelf to the legs using screws (AA) and bolts (BB).



These side holes are used for installing the handle. Leave one of the sides open to install the handle.



**BRACKET TO THE INSIDE**




AA




BB

## STEP 2


Slide the middle and bottom shelves onto the rear legs. Slide the front legs on. **LOOSELY** install hardware to each corner, remembering to leave access for the handle.




Slide on middle shelf.




Slide on bottom shelf.



Slide on front legs.



INSTALL HARDWARE TO EACH CORNER, OMIT HANDLE SIDE




AA



BB


### STEP 3

Install handle to either side of the cart using bolts (CC) and nuts (BB).



### STEP 4


Secure tube and top shelf together using screws (DD) and nuts (EE).



**NOW TIGHTEN ALL CART CORNER HARDWARE**


## STEP 5

Push a caster into each leg insert. To ensure casters are securely in place, a rubber mallet may be used to tap them in place. **NOTE:** The locking casters **MUST** be installed on the same side as the handle.



## STEP 6

Attach the monitor bracket onto the front of the rear leg tubes as shown using bolts (FF) and nuts (GG).





# SKIP TO STEP 12 IF YOUR CART DOES NOT HAVE A SHELF

## STEP 7



Attach each shelf bracket under the top shelf as shown using screws (HH).

Make sure the bracket cutouts face this way, if not the bracket will be installed upside down.



## STEP 8

Install the outer slide onto the shelf bracket by sliding TAB 1 into CUTOUT A and TAB 2 into CUTOUT B.  
The pull out shelf should be installed opposite of the handle.




This tab determines where the shelf will slide out from.

Each cart bracket has additional cutouts to allow the shelf to pull out from either side of the cart.

**NOTE:** Some bend in the bracket is ok as the slides and shelf will take care of that once they are installed.


## STEP 9

Install each inner slide into the outer slides. **NOTE: Push inner slide in all the way until it snaps in.**





## STEP 10

Extend the slides to the positioning shown.



## STEP 11


Install the pull out shelf by sliding **CUTOUT 1** into **TAB 1** and **CUTOUT 2** into **TAB 2**.






## STEP 12

Attach both hook bars onto the back of your monitor using the mounting holes built into the case. A courtesy hardware pack has been provided with several metric screw sizes. You may need to purchase additional metric screws from your local hardware store for odd shaped monitors.




## STEP 13

With someone's help, hook your monitor onto the bracket as shown. (Monitor removed from picture for clarity.)




## STEP 14

Attach the stop brackets to the hook bars as shown with security screws (II) using the driver bit provided.



## STEP 15

Center your monitor horizontally and then tighten in place with screws (JJ).



**CENTER MONITOR HORIZONTALLY THEN SECURE**

Bretford  
11000 Seymour Avenue  
Franklin Park, IL 60131  
TEL: 847.678.2545  
800.521.9614  
FAX: 847.678.0852  
800.343.1779

Bretford Ltd.  
2 Etongate  
110 Windsor Road, Slough  
Berkshire SL1 2JA England  
TEL: 011 44 17 5353 9955  
FAX: 011 44 17 5353 9478

[www.bretford.com](http://www.bretford.com)

Part # 031-8665  
Rev. 05.11.11 CZ