


MOBILEPRO™ Mobile Workstation


Quick Start Guide



UNBOXING GUIDE



1. Cut sides of the packaging and remove all packaging materials.




2. Unlock the caster brakes and roll the unit off the pallet.


Weight Limits

Work-surface: Up to 30 lbs.
 Printer Shelf: Up to 15 lbs.
 Slide-Out Printer Shelf: Up to 50 lbs.
 Storage Cabinet: Up to 30 lbs.


PRODUCT SETUP




1. Insert the swappable battery into the receiver.




2. Turn on the back up battery by holding the power button on for two seconds.




3. Charge the battery: Included is a power cord. Plug the power cord into the cart and into a wall outlet and charge until the battery is fully charged.





4. Mount your monitor: (a) With a Philips screwdriver, loosen the (4) fasteners on the monitor mount.



(b) Remove the monitor mount and attach it to your monitor (up to 34").



(c) Once secured, attach the monitor mount over the (4) fasteners on the cart and tighten.



5. Insert the included Velcro straps in the designated areas on the workstation to secure and organize cords as needed. Wrap the Velcro around the cords and press firmly.